L70+/L70F-PEN4 L70+/L70F/P5 DIP SWITCHES SETTING: 1(Pulse/ccTalk/ICT104U)

Supported bill PEN 10, 20, 50, 100 4bills.

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|---|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| * | 1 Pulse / PEN 10 | OFF | OFF | OFF | | | | | | | |
| | 2 Pulses / PEN 10 | OFF | OFF | ON | | | | | | | |
| | 3 Pulses / PEN 10 | OFF | ON | OFF | | | | | | | |
| | 4 Pulses / PEN 10 | OFF | ON | ON | | | | | | | |
| | 5 Pulses / PEN 10 | ON | OFF | OFF | | | | | | | |
| | 10 Pulses / PEN 10 | ON | OFF | ON | | | | | | | |
| | 20 Pulses / PEN 10 | ON | ON | OFF | | | | | | | |
| | 100 Pulses / PEN 10 | ON | ON | ON | | | | | | | |
| | Fast output Pulse Lo= 50ms Hi=100ms | | | | ON | | | | | | |
| * | Slow output Pulse Lo= 50ms Hi=300ms | | | | OFF | | | | | | |
| | Inhibit level Active Low | | | | | ON | | | | | |
| * | Inhibit level Active High | | | | | OFF | | | | | |
| * | Accept PEN 10 | | | | | | ON | | | | |
| | Reject PEN 10 | | | | | | OFF | | | | |
| * | Accept PEN 20 | | | | | | | ON | | | |
| | Reject PEN 20 | | | | | | | OFF | | | |
| * | Accept PEN 50 | | | | | | | | ON | | |
| | Reject PEN 50 | | | | | | | | OFF | | |
| * | Accept PEN 100 | | | | | | | | | ON | |
| | Reject PEN 100 | | | | | | | | | OFF | |
| * | Reserve | | | | | | | | | | ON |
| | Reserve | | | | | | | | | | OFF |

★ Manufacture setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

- (2) Dip switches 1 to 5 are only used for pulse protocol.
- (3) Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

L70+/L70F-PEN4(Pulse/ccTalk/ICT104U)

DIP SWITCHES SETTING: 2(Pulse)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|--|-----|-----|-----|-----|
| * | Pulse Normal High | ON | | | |
| | Pulse Normal Low | OFF | | | |
| * | Pulse Mode | | ON | OFF | |
| | ccTalk Interface | | OFF | OFF | |
| | ccTalk Parameters Restore Switch Please see "Note" for detail | | OFF | ON | |
| | ICT104U Interface | | ON | ON | |
| | Reserved | | | | ON |
| * | Veselven | | | | OFF |

Currency Assign Data

| Interface Bill value | Pulse | ICT104U | ccTalk |
|-------------------------|-------|---------|--------|
| BV1 | 10 | 10 | 10 |
| BV2 | 20 | 20 | 20 |
| BV3 | 50 | 50 | 50 |
| BV4 | 100 | 100 | 100 |

DIP SWITCHES SETTING: 2(ccTalk)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|--|-----|-----|-----|-----|
| | 8-bit checksum | ON | | | |
| * | CRC 16-bit checksum | OFF | | | |
| | Pulse Mode | | ON | OFF | |
| * | ccTalk Interface | | OFF | OFF | |
| | ccTalk Parameters Restore Switch Please see "Note" for detail | | OFF | ON | |
| | ICT104U Interface | | ON | ON | |
| * | Encryption Mode | | | | ON |
| | Decrypt Mode | | | | OFF |
| | Decrypt Mode | | | | OF |

Decrypt MODE

| | 8-bit | CRC 16-bit | | |
|-----------------|----------|------------|--|--|
| Encryption MODE | Reserved | ON | | |
| Decrypt MODE | Reserved | OFF | | |

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING: 2(ICT104U)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|--|-----|-----|-----|-----|
| k | Reserved | | | | |
| | 1/6961Aen | OFF | | | |
| | Pulse Mode | | ON | OFF | |
| | ccTalk Interface | | OFF | OFF | |
| | ccTalk Parameters Restore Switch Please see "Note" for detail | | OFF | ON | |
| k | ICT104U Interface | | ON | ON | |
| | Reserved | | | | ON |
| ĸ | | | | | OFF |

[★] Manufacture setting

[★] Manufacture setting

[★] Manufacture setting