

## P77-PLN5

### P77/P2/P5 DIP SWITCHES SETTING : 1(Pulse/ccTalk)

Supported bill zloty 10, 20, 50, 100, 200 5bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / zloty 10	OFF	OFF	OFF							
	2 Pulse / zloty 10	OFF	OFF	ON							
	3 Pulse / zloty 10	OFF	ON	OFF							
	4 Pulse / zloty 10	OFF	ON	ON							
	5 Pulse / zloty 10	ON	OFF	OFF							
	10 Pulse / zloty 10	ON	OFF	ON							
	20 Pulse / zloty 10	ON	ON	OFF							
	100 Pulse / zloty 10	ON	ON	ON							
★	Fast output Pulse    Lo= 50ms 										

(★) Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

## P77-PLN5/P2/P5(Pulse/ccTalk)

### DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Protocol		ON		
	ccTalk Protocol		OFF		
	Harness Disable			ON	
★	Harness Enable			OFF	
	Reserved				ON
★	Reserved				OFF

★ Manufacture setting

### DIP SWITCHES SETTING : 2(ccTalk)

	FUNCTION	SW1	SW2	SW3	SW4
★	Encryption Mode	ON			
	Decrypt Mode	OFF			
	Pulse Protocol		ON		
★	ccTalk Protocol		OFF		
	ccTalk Parameters Reset			ON	
★	Keep ccTalk Parameters			OFF	
	Reserved				ON
★	Reserved				OFF

★ Manufacture setting.

Note : 1.Please reset the bill acceptor after set the dip switch.

2.RS232 BI Parameters Reset

Put this switch to on and reset power will restore the RS232 BI address to its default value of 40 and the encryption key to its default value of 123456.

\*This has to be done after finished calibration process.

### Currency Assign Data

Interface Bill value	Pulse	ccTalk
BV1	10	10
BV2	20	20
BV3	50	50
BV4	100	100
BV5	200	200