

ROL4

P77/P5 DIP SWITCHES SETTING : 1(Pulse/Parallel A3)

Supported bill Lei 1, 5, 10, 50 4 bills.

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 | | | |
|---|---------------------------|----------------------|-----|-----|-----|-----|-----|-----|-----|-----|------|----|----|----|
| ★ | 1 Pulse / Lei 1 | OFF | OFF | OFF | | | | | | | | | | |
| | 2 Pulses / Lei 1 | OFF | OFF | ON | | | | | | | | | | |
| | 3 Pulses / Lei 1 | OFF | ON | OFF | | | | | | | | | | |
| | 4 Pulses / Lei 1 | OFF | ON | ON | | | | | | | | | | |
| | 5 Pulses / Lei 1 | ON | OFF | OFF | | | | | | | | | | |
| | 10 Pulses / Lei 1 | ON | OFF | ON | | | | | | | | | | |
| | 20 Pulses / Lei 1 | ON | ON | OFF | | | | | | | | | | |
| | 100 Pulses / Lei 1 | ON | ON | ON | | | | | | | | | | |
| | Fast output Pulse | Lo= 50ms Hi=100ms | | | | | | | | | | ON | | |
| ★ | Slow output Pulse | Lo= 50ms Hi=300ms | | | | OFF | | | | | | | | |
| | Inhibit level Active Low | | | | | ON | | | | | | | | |
| ★ | Inhibit level Active High | | | | | OFF | | | | | | | | |
| ★ | Accept Lei 1 | | | | | | | | | | ON | | | |
| | Reject Lei 1 | | | | | | OFF | | | | | | | |
| ★ | Accept Lei 5 | | | | | | | | | | | ON | | |
| | Reject Lei 5 | | | | | | | OFF | | | | | | |
| ★ | Accept Lei 10 | | | | | | | | | | | | ON | |
| | Reject Lei 10 | | | | | | | | OFF | | | | | |
| ★ | Accept Lei 50 | | | | | | | | | | | | | ON |
| | Reject Lei 50 | | | | | | | | | OFF | | | | |
| | Reserved | | | | | | | | | | | | | |
| ★ | Reserved | | | | | | | | | | OFF | | | |

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

P77-ROL4/P5(Pulse/Parallel A3)

DIP SWITCHES SETTING : 2(Pulse)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|-------------------------------------|-----|-----|-----|-----|
| ★ | Credit-Pulse Normal HIGH | ON | | | |
| | Credit-Pulse Normal LOW | OFF | | | |
| ★ | Pulse Protocol | | ON | | |
| | Parallel A3 Protocol | | OFF | | |
| | Harness Disable | | | ON | |
| ★ | Harness Enable | | | OFF | |
| | Ignore Sensor Problem (Note 1) | | | | ON |
| ★ | Acknowledge Sensor Problem (Note 2) | | | | OFF |

★ Manufacture setting

DIP SWITCHES SETTING : 3(Parallel A3)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|-------------------------------------|-----|-----|-----|-----|
| ★ | Reserved | ON | | | |
| | | OFF | | | |
| | Pulse Protocol | | ON | | |
| ★ | Parallel A3 Protocol | | OFF | | |
| ★ | Reserved | | | ON | |
| | | | | OFF | |
| | Ignore Sensor Problem (Note 1) | | | | ON |
| ★ | Acknowledge Sensor Problem (Note 2) | | | | OFF |

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)