

UAH6**P77/P5 DIP SWITCHES SETTING : 1(Pulse/RS232 A0)**

Supported bill H 1, 2, 5, 10, 20, 50 6bills.

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|---|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| ★ | 1 Pulse / H 1 | OFF | OFF | OFF | | | | | | | |
| | 2 Pulses / H 1 | OFF | OFF | ON | | | | | | | |
| | 3 Pulses / H 1 | OFF | ON | OFF | | | | | | | |
| | 4 Pulses / H 1 | OFF | ON | ON | | | | | | | |
| | 5 Pulses / H 1 | ON | OFF | OFF | | | | | | | |
| | 10 Pulses / H 1 | ON | OFF | ON | | | | | | | |
| | 20 Pulses / H 1 | ON | ON | OFF | | | | | | | |
| | 100 Pulses / H 1 | ON | ON | ON | | | | | | | |
| | Fast output Pulse Lo= 50ms Hi=100ms | | | | ON | | | | | | |
| ★ | Slow output Pulse Lo= 50ms Hi=300ms | | | | OFF | | | | | | |
| | Inhibit level Active Low | | | | | ON | | | | | |
| ★ | Inhibit level Active High | | | | | OFF | | | | | |
| ★ | Accept H 1 & 2 | | | | | | ON | | | | |
| | Reject H 1 & 2 | | | | | | OFF | | | | |
| ★ | Accept H 5 | | | | | | | ON | | | |
| | Reject H 5 | | | | | | | OFF | | | |
| ★ | Accept H 10 | | | | | | | | ON | | |
| | Reject H 10 | | | | | | | | OFF | | |
| ★ | Accept H 20 | | | | | | | | | ON | |
| | Reject H 20 | | | | | | | | | OFF | |
| ★ | Accept H 50 | | | | | | | | | | ON |
| | Reject H 50 | | | | | | | | | | OFF |

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

P77-UAH6/P5(Pulse/RS232 A0)**DIP SWITCHES SETTING : 2(Pulse)**

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|---------------------|-----|-----|-----|-----|
| ★ | Pulse Normal High | ON | | | |
| | Pulse Normal Low | OFF | | | |
| ★ | Pulse Protocol | | ON | | |
| | RS232 A0 Protocol | | OFF | | |
| | Harness Disable | | | ON | |
| ★ | Harness Enable | | | OFF | |
| | Manufacture Default | | | | ON |
| ★ | System Default | | | | OFF |

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 & 3 are only used for pulse protocol.

DIP SWITCHES SETTING : 2(RS232 A0)

| | FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|---------------------|-----|-----|-----|-----|
| ★ | Reserved | ON | | | |
| | Reserved | OFF | | | |
| | Pulse Protocol | | ON | | |
| ★ | RS232 A0 Protocol | | OFF | | |
| | Reserved | | | ON | |
| ★ | Reserved | | | OFF | |
| | Manufacture Default | | | | ON |
| ★ | System Default | | | | OFF |

★ Manufacture setting