

**TAO-A.V Option Switch Settings: 1(Pulse/ICT/MDB/ICT for VCCS)**

**Supported bill PRs 10, 20, 50, 100, 500 5bills.**

TAO-V dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject PRs 10	ON											
	Accept PRs 10	OFF											
	Reject PRs 20		ON										
★	Accept PRs 20		OFF										
	Reject PRs 50			ON									
★	Accept PRs 50			OFF									
	Reject PRs 100				ON								
★	Accept PRs 100				OFF								
	Reject PRs 500					ON							
★	Accept PRs 500					OFF							
	Reserved						ON						
★	Reserved						OFF						
	Harness Disable							ON					
★	Harness Enable							OFF					
	Inhibit Active High								ON				
★	Inhibit Active Low								OFF				
★	1 pulse / PRs 10									OFF	OFF		
	5 pulses / PRs 10									ON	OFF		
	10 pulses / PRs 10									OFF	ON		
	20 pulses / PRs 10									ON	ON		
★	Interface Timing Conversion	50ms on / 50ms off								OFF	OFF		
		60ms on / 300ms off								ON	OFF		
		30ms on / 50ms off								OFF	ON		
		150ms on / 150ms off								ON	ON		

★ Manufacture setting

◆ Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

(3) BV1=PRs 10, Bv2=PRs 20, Bv3=PRs 50, Bv4=PRs 100, Bv5=PRs 500.

**Interface Settings: 2(Pulse)**

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON	OFF	
	ICT Mode		OFF	OFF	
	ICT for VCCS		OFF	ON	
	MDB Interface		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

**Interface Settings: 2(ICT/ICT for VCCS)**

	INTERFACE	SW1	SW2	SW3	SW4
★	Not Used	ON			
	Not Used	OFF			
	Pulse Mode		ON	OFF	
★	ICT Mode		OFF	OFF	
	ICT for VCCS		OFF	ON	
	MDB Interface		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

	INTERFACE	SW1	SW2	SW3	SW4
★	Not Used	ON			
	Not Used	OFF			
	Pulse Mode		ON	OFF	
	ICT Mode		OFF	OFF	
★	ICT for VCCS		OFF	ON	
	MDB Interface		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

**TAO-V-PKR5**

**Interface Settings: 2(MDB)**

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT Mode		OFF	ON	
	ICT for VCCS		OFF	ON	
★	MDB Interface		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting