V7-AMD2

V7 Option Switch Settings:1(Pulse/ccTalk) Supported bill DRAMS 1000, 2000 2bills.

V7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject DRAMS 1000	ON											
*	Accept DRAMS 1000	OFF											
	Reject DRAMS 2000		ON										
*	Accept DRAMS 2000		OFF										
	Reserved			ON									
*	Reserved			OFF									
	Reserved				ON								
*	Reserved				OFF								
	Reserved					ON							
*	Reserved					OFF							
	Reserved						ON						
*	Reserved						OFF						
	Harness Disable						ON						
*	Harness Enable	OFF											
	Inhibit Active High	C					ON						
*	Inhibit Active Low	OFF											
*	1 pulse / DRAMS 1000	OFF OFF											
	2 pulse / DRAMS 1000	ON OF						OFF					
	4 pulse / DRAMS 1000							OFF	ON				
	20 pulse / DRAMS 1000									ON	ON		
*		50n	ns LO	/ 50)ms F	11						OFF	OFF
	Pulse Speed	60ms LO / 300ms HI							ON	OFF			
	. 4.00 0000	30ms LO / 50ms HI							OFF	ON			
		150n	ns LO	/ 150)ms ⊦	11						ON	ON

- Manufacture setting.
- Factory configuration has all switches in the OFF position.
 - Note: (1) Reset the bill acceptor after setting the dip switch.
 - (2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.
 - (3) cctalk Parameters Restore Switch Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

Appendix

V7-AMD2(Pulse/ccTalk)

Interface Settings: 2(Pulse) Currency Assign Data

	INTERFACE	SW1	SW2	SW3	SW4
*	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
*	Pulse Mode		ON		
	ccTalk Interface Mode		OFF		
*				ON	
	Reserved			OFF	
			ON		
*			OFF		

Interface Bill value	Pulse	ccTalk		
BV1	DRAMS 1000	DRAMS 1000		
BV2	DRAMS 2000	DRAMS 2000		

Interface Settings: 2(ccTalk)

	INTERFACE	SW1	SW2	SW3	SW4
*	Reserved	ON			
	Neserved	OFF			
	Pulse Mode		ON		
*	ccTalk Interface Mode		OFF		
•	ccTalk Parameters Restore Switch (Please see Note.3 for detail) (ccTalk only)			ON	
*	Reserved			OFF	
	Reserved	·	ON		
*	Neserved		OFF		

- ★ Manufacture setting
- ▲ Note:3 cctalk Parameters Restore Switch

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.