V7-GEL4

V7 Option Switch Settings: 1 (Pulse/ICT004U/MDB)

Supported bill GEL 5, 10, 20, 50 4bills.

V7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject GEL 5	ON							
*	Accept GEL 5	OFF							
	Reject GEL 10		ON						
*	Accept GEL 10		OFF						
	Reject GEL 20			ON					
*	Accept GEL 20			OFF					
	Reject GEL 50			•	ON				
*	Accept GEL 50				OFF				
	Reserved					ON			
*	Reserved					OFF			
	Reserved						ON		
*	Reserved						OFF		
	Harness Disable							ON	
*	Harness Engble							OFF	
	Inhiblit Active High								ON
*	Inhibit Active Low								OFF

Factory configuration has all switches in the OFF position.

V7 Interface Settings: 2 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
*	1 pulse / GEL 5	OFF	OFF		
	2 pulse / GEL 5	ON	OFF		
	5 pulse / GEL 5	OFF	ON		
	20 pulse / GEL 5	ON	ON		
*	50ms LO / 50ms HI			OFF	OFF
	60ms LO / 300ms HI				OFF
	30ms LO / 50ms HI			OFF	ON
	150ms LO / 150ms HI			ON	ON

[★] Manufacture setting

V7-GEL4(Pulse/ICT004U/MDB)

V7 Interface Settings: 3 (ICT004U) V7 Interface Settings: 3 (Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
	Reserved	ON			
Ł	Reserved	OFF			
	Pulse Mode		ON	OFF	
	MDB Interface		OFF	OFF	
Ł	ICT004U Interface		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
Ł	i vesel veu				OFF

	INTERFACE	SW1	SW2	SW3	SW4
*	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
*	Pulse Mode		ON	OFF	
	MDB Interface		OFF	OFF	
	ICT004U Interface		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
*	iveset/60				OFF

V7 Interface Settings: 3 (MDB)

	INTERFACE	SW1	SW2	SW3	SW4
*	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
*	MDB Interface		OFF	OFF	
	ICT004U Interface		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
*	Reserved				OFF

Currency Assign Data

Interface Bill value	erface ICT004U Pulse		MDB
BV1	GEL 5	GEL 5	GEL 5
BV2	GEL 10	GEL 10	GEL 10
BV3	GEL 20	GEL 20	GEL 20
BV4	GEL 50	GEL 50	GEL 50

Note: 1.Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2.Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "Sw1" setting.)