

# V77E-INR6

## V77E Option Switch Settings : 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill INR 10, 20, 50, 100, 200, 500 6bills.

V77E dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject INR 10 & 20	ON											
★ Accept INR 10 & 20	OFF											
Reject INR 50		ON										
★ Accept INR 50		OFF										
Reject INR 100			ON									
★ Accept INR 100			OFF									
Reject INR 200				ON								
★ Accept INR 200				OFF								
Reject INR 500					ON							
★ Accept INR 500					OFF							
★ Medium Security					ON							
High Security					OFF							
<b>Pulse Mode</b>	<b>Other Mode</b>											
Harness Disable	BA stops working when fishing						ON					
★ Harness Enable	Normal						OFF					
Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / INR 10									OFF	OFF		
2 pulses / INR 10									ON	OFF		
4 pulses / INR 10									OFF	ON		
20 pulses / INR 10									ON	ON		
★ Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
	60ms LO / 300ms HI								ON	OFF		
	30ms LO / 50ms HI								OFF	ON		
	150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

# V77E-INR6(Pulse/ICT104V/ICT104U/MDB)

## Interface Settings: 2(Pulse) Currency Assign Data

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Interface		ON	OFF	
ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting

Interface Bill value	ICT104U	ICT104V	Pulse	MDB
BV1				
BV2	INR 10	INR 10	INR 10	INR 10
BV3	INR 20	INR 20	INR 20	INR 20
BV4	INR 50	INR 50	INR 50	INR 50
BV5	INR 100	INR 100	INR 100	INR 100
BV6	INR 200	INR 200	INR 200	INR 200
BV7	INR 500	INR 500	INR 500	INR 500

## Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Interface		ON	OFF	
★ ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting

## Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Interface		ON	OFF	
ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
★ ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting

## Interface Settings: 2(MDB)

INTERFACE	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Interface		ON	OFF	
★ ICT104V Interface		OFF	ON	
MDB Interface		ON	ON	
ICT104U Interface		OFF	OFF	
Reserved				ON
				OFF

★ Manufacture setting