

V77E-KZT5

V77E Option Switch Settings : 1(Pulse/RS232 A0/ccNet)

Supported bill KZT 200, 500, 1000, 2000, 5000 5bills.

V77E dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject KZT 200	ON											
	Accept KZT 200	OFF											
	Reject KZT 500		ON										
★	Accept KZT 500		OFF										
	Reject KZT 1000			ON									
★	Accept KZT 1000			OFF									
	Reject KZT 2000				ON								
★	Accept KZT 2000				OFF								
	Reject KZT 5000				ON								
★	Accept KZT 5000				OFF								
	Reserved				ON								
★	Reserved				OFF								
	Harness Disable					ON							
★	Harness Enable					OFF							
	Inhibit Active High						ON						
★	Inhibit Active Low						OFF						
★	1 pulse / KZT 100								OFF	OFF			
	2 pulse / KZT 100								ON	OFF			
	5 pulse / KZT 100								OFF	ON			
	20 pulse / KZT 100								ON	ON			
★	Pulse Speed	50ms on / 50ms off									OFF	OFF	
		60ms on / 300ms off									ON	OFF	
		30ms on / 50ms off									OFF	ON	
		150ms on / 150ms off									ON	ON	

★ Manufacture setting

◆ Factory configuration has all switches in the OFF position.

Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW6.SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

V77E-KZT5(Pulse/RS232 A0/ccNet)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
	RS232 A0 Interface		OFF	ON	
	ccNet Interface		ON	ON	
★	Pulse Interface		ON	OFF	
	Reserved		OFF	OFF	
	Reserved				ON
★					OFF

★ Manufacture setting

Interface Settings: 2(RS232 A0)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	RS232 A0 Interface		OFF	ON	
	ccNet Interface		ON	ON	
	Pulse Interface		ON	OFF	
	Reserved		OFF	OFF	
	Reserved				ON
★					OFF

★ Manufacture setting

Interface Settings: 2(ccNet)

	INTERFACE	SW1	SW2	SW3	SW4
	Baud rate 19200	ON			
★	Baud rate 9600	OFF			
	RS232 A0 Interface		OFF	ON	
★	ccNet Interface		ON	ON	
	Pulse Interface		ON	OFF	
	Reserved		OFF	OFF	
	Reserved				ON
★					OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	RS232 A0	ccNet
BV1	200	200	200
BV2	500	500	500
BV3	1000	1000	1000
BV4	2000	2000	2000
BV5	5000	5000	5000