

V7E-TRY5

V7E Option Switch Settings: 1(Pulse/ICT/MDB)

Supported bill TRY 5, 10, 20, 50, 100 5 bills.

V7E dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject TRY 5	ON											
★ Accept TRY 5	OFF											
★ Reject TRY 10		ON										
★ Accept TRY 10		OFF										
★ Reject TRY 20			ON									
★ Accept TRY 20			OFF									
★ Reject TRY 50				ON								
★ Accept TRY 50				OFF								
★ Reject TRY 100					ON							
★ Accept TRY 100					OFF							
★ Reserved					ON							
★ Reserved					OFF							
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / TRY 5									OFF	OFF		
5 pulses / TRY 5									ON	OFF		
10 pulses / TRY 5									OFF	ON		
20 pulses / TRY 5									ON	ON		
★ Pulse Speed		50ms on / 50ms off									OFF	OFF
		60ms on / 300ms off									ON	OFF
		30ms on / 50ms off									OFF	ON
		150ms on / 150ms off									ON	ON

★ Manufacture setting

Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

V7E-TRY5

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
ICT Interface		OFF	ON	
MDB Interface		ON	ON	
★ Reserved				ON
				OFF

Currency Assign Data

Interface Bill value	Pulse	MDB	ICT
BV1	TRY 5	TRY 5	TRY 5
BV2	TRY 10	TRY 10	TRY 10
BV3	TRY 20	TRY 20	TRY 20
BV4	TRY 50	TRY 50	TRY 50
BV5	TRY 100	TRY 100	TRY 100

DIP SWITCHES SETTING : 3(ICT)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
	OFF			
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
★ Reserved				ON
				OFF

DIP SWITCHES SETTING : 4(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
★ ICT Interface		OFF	ON	
MDB Interface		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.