

## V7E/LX7-XCD3

### V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/MDB/ICT104V)

Supported bill XCD 5, 10, 20 3bills.

V7E/LX7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	
★	Reject XCD 5	ON												
★	Accept XCD 5	OFF												
★	Reject XCD 10		ON											
★	Accept XCD 10		OFF											
★	Reject XCD 20			ON										
★	Accept XCD 20			OFF										
★	Reserved			ON										
★	Reserved			OFF										
★	Reserved				ON									
★	Reserved				OFF									
★	Reserved					ON								
★	Reserved					OFF								
	<b>Pulse Mode</b>	<b>Other Mode</b>												
★	Harness Disable	BA stops working when fishing								ON				
★	Harness Enable	Normal								OFF				
★	Inhibit Active High								ON					
★	Inhibit Active Low								OFF					
★	1 pulse / XCD 5									OFF	OFF			
★	5 pulses / XCD 5									ON	OFF			
★	10 pulses / XCD 5									OFF	ON			
★	25 pulses / XCD 5									ON	ON			
★	Pulse Speed	50ms LO / 50ms HI									OFF	OFF		
		60ms LO / 300ms HI									ON	OFF		
		30ms LO / 50ms HI									OFF	ON		
		150ms LO / 150ms HI									ON	ON		

★ Manufacture setting

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

## V7E/LX7-XCD3(Pulse/ICT104U/MDB/ICT104V)

### DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
	ICT104V Interface		ON	ON	
	MDB Interface		OFF	OFF	
★	Reserved				ON
					OFF

### Currency Assign Data

Interface Bill value	ICT104U	Pulse	MDB	ICT104V
BV1	XCD 5	XCD 5	XCD 5	XCD 5
BV2	XCD 10	XCD 10	XCD 10	XCD 10
BV3	XCD 20	XCD 20	XCD 20	XCD 20

### DIP SWITCHES SETTING : 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Interface		OFF	ON	
	ICT104V Interface		ON	ON	
	MDB Interface		OFF	OFF	
★	Reserved				ON

### DIP SWITCHES SETTING : 2(ICT104V)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Interface		OFF	ON	
	ICT104V Interface		ON	ON	
	MDB Interface		OFF	OFF	
★	Reserved				ON

### DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
★	ICT104V Interface		ON	ON	
	MDB Interface		OFF	OFF	
★	Reserved				ON

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.