L83-RSD8 L83 DIP SWITCHES SETTING : 1(Pulse/ICT104U/RS232 A0)Supported bill RSD 10, 20, 50, 100, 200, 500, 1000, 2000 8 bills.

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|---|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| | 1 Pulse / RSD 10 | OFF | OFF | OFF | | | | | | | |
| | 2 Pulses / RSD 10 | OFF | OFF | ON | | | | | | | |
| | 3 Pulses / RSD 10 | OFF | ON | OFF | | | | | | | |
| | 4 Pulses / RSD 10 | OFF | ON | ON | | | | | | | |
| Г | 5 Pulses / RSD 10 | ON | OFF | OFF | | | | | | | |
| Г | 10 Pulses / RSD 10 | ON | OFF | ON | | | | | | | |
| Г | 20 Pulses / RSD 10 | ON | ON | OFF | | | | | | | |
| Г | 100 Pulses / RSD 10 | ON | ON | ON | | | | | | | |
| Г | Fast output Pulse Lo= 50ms Hi=100ms | | | | ON | | | | | | |
| Г | Slow output Pulse Lo= 50ms Hi=300ms | | | | OFF | | | | | | |
| Г | Inhibit level Active Low | | | | | ON | | | | | |
| Г | Inhibit level Active High | | | | | OFF | | | | | |
| | Accept RSD 10 & 20 | | | | | | ON | | | | |
| Г | Reject RSD 10 & 20 | | | | | | OFF | | | | |
| Г | Accept RSD 50 & 100 | | | | | | | ON | | | |
| Г | Reject RSD 50 & 100 | | | | | | | OFF | | | |
| Г | Accept RSD 200 & 500 | | | | | | | | ON | | |
| Г | Reject RSD 200 & 500 | | | | | | | | OFF | | |
| Г | Accept RSD 1000 | | | | | | | | | ON | |
| Г | Reject RSD 1000 | | | | | | | | | OFF | |
| Г | Accept RSD 2000 | | | | | | | | | | ON |
| r | Reject RSD 2000 | | | | | | | | | | OFF |

★ Manufacture setting

Note: (1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip switches 1 to 5 are only for Pulse mode.

L83-RSD8(Pulse/ICT104U/RS232 A0)

DIP SWITCHES SETTING: 2(Pulse) Currency Assign Data

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | |
|---|-------------------|-----|-----|-----|-----|--|
| * | Pulse Normal High | | | | | |
| | Pulse Normal Low | | | | | |
| * | Pulse Mode | | ON | OFF | | |
| | ICT104U Interface | | OFF | ON | | |
| | RS232 A0 Mode | | ON | ON | | |
| | Reserved | | OFF | OFF | | |
| | Reserved | | | | ON | |
| * | | | | | | |

| Interface Bill value | Pulse | RS232 A0 | ICT104U | |
|-------------------------|----------|----------|----------|--|
| BV1 | RSD 10 | RSD 10 | RSD 10 | |
| BV2 | RSD 20 | RSD 20 | RSD 20 | |
| BV3 | RSD 50 | RSD 50 | RSD 50 | |
| BV4 | RSD 100 | RSD 100 | RSD 100 | |
| BV5 | RSD 200 | RSD 200 | RSD 200 | |
| BV6 | RSD 500 | RSD 500 | RSD 500 | |
| BV7 | RSD 1000 | RSD 1000 | RSD 1000 | |
| BV8 | RSD 2000 | RSD 2000 | RSD 2000 | |

DIP SWITCHES SETTING: 2(ICT104U)

| | FUNCTION | | SW2 | SW3 | SW4 |
|---|-------------------|----|-----|-----|-----|
| | Doggrand | ON | | | |
| * | Reserved | | | | |
| | Pulse Mode | | ON | OFF | |
| * | ICT104U Interface | | OFF | ON | |
| | RS232 A0 Mode | | ON | ON | |
| | Reserved | | OFF | OFF | |
| | Reserved | | | | ON |
| * | | | | | |

[★] Manufacture setting

DIP SWITCHES SETTING: 2(RS232 A0)

| | FUNCTION | | SW2 | SW3 | SW4 |
|---|-------------------|--|-----|-----|-----|
| * | Reserved | | | | |
| | Pulse Mode | | ON | OFF | |
| | ICT104U Interface | | OFF | ON | |
| * | RS232 A0 Mode | | ON | ON | |
| | Reserved | | OFF | OFF | |
| | Reserved | | | | ON |
| * | Neserveu | | OFF | | |

[★] Manufacture setting

| RS232 A0 INFORMATION | | | | | | |
|----------------------|---------------|--|--|--|--|--|
| Bill | BillType Data | | | | | |
| Code | Denomination | | | | | |
| 1 | RSD 10 | | | | | |
| 2 | RSD 20 | | | | | |
| 3 | RSD 50 | | | | | |
| 4 | RSD 100 | | | | | |
| 5 | RSD 200 | | | | | |
| 6 | RSD 500 | | | | | |
| 7 | RSD 1000 | | | | | |
| 8 | Reserved | | | | | |
| 9 | RSD 2000 | | | | | |

[★] Manufacture setting