

XBA mini-KRW4

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104U/ICT104V)

Supported bill KRW 1000, 5000, 10000, 50000 4bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject KRW 1000	ON											
★ Accept KRW 1000	OFF											
Reject KRW 5000		ON										
★ Accept KRW 5000		OFF										
Reject KRW 10000			ON									
★ Accept KRW 10000			OFF									
Reject KRW 50000				ON								
★ Accept KRW 50000				OFF								
Reserved					ON							
★ Reserved					OFF							
Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ EnableBill Reject 4 Times BA Stop By 30 Sec						OFF						
Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ Reserved								ON				
★ Reserved								OFF				
Pulse Mode	SW1	SW2	SW3	SW4	MDB Mode							
Inhibit Active High	ON				★ Normal				OFF	OFF		
★ Inhibit Active Low	OFF				DIV 10				ON	OFF		
Reserved		ON			DIV 100				OFF	ON		
★ Reserved		OFF			DIV 1000				ON	ON		
★ Interface	50ms LO / 50ms HI		OFF	OFF	Reserved						ON	
Timing	60ms LO / 300ms HI		ON	OFF	★ Reserved						OFF	
Conversion	30ms LO / 50ms HI		OFF	ON	Reserved							ON
	150ms LO / 150ms HI		ON	ON	★ Reserved							OFF

★ Manufacture setting

Note :(1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

(2) Calibration card is needed.

(3) ** MDB Mode:

Scaling Factor (SF) = 1

Decimal Point Position (DPP) = 0

XBA mini-KRW4(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ 1 pulse / KRW 1000			OFF	OFF
5 pulses / KRW 1000			OFF	ON
10 pulses / KRW 1000			ON	OFF
20 pulses / KRW 1000			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	KRW 1000	KRW 1000	KRW 1000	KRW 1000	KRW 1000
BV2		KRW 5000	KRW 5000	KRW 5000	KRW 5000
BV3		KRW 10000	KRW 10000	KRW 10000	KRW 10000
BV4		KRW 50000	KRW 50000	KRW 50000	KRW 50000

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

FUNCTION	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD Converter board	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting