
XBA-TRY6 Option Switch Settings

Supported bill Lira 5, 10, 20, 50, 100, 200 6bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject Lira 5	ON							
*	Accept Lira 5	OFF							
	Reject Lira 10		ON						
*	Accept Lira 10		OFF						
	Reject Lira 20			ON					
*	Accept Lira 20			OFF					
	Reject Lira 50				ON				
*	Accept Lira 50				OFF				
	Reject Lira 100 & 200					ON			
*	Accept Lira 100 & 200								
	Disable Bill Reject 4 Times BA Stop By 30 Sec						ON		
*	Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF		
	Stack Banknote when Power-up							ON	
*	Reject Banknote when Power-up	OFF							
	Reserved								ON
*	Reserved								OFF

This dip switch is located at the side of XBA.



Currency Assign Data

nterface Bill value	Pulse	JPSTD	ccTalk	ICT104U	RS232 A0	
BV1	Lira 5	Lira 5	Lira 5	Lira 5	Lira 5	
BV2	Lira 10		Lira 10	Lira 10	Lira 10	
BV3	Lira 20		Lira 20	Lira 20	Lira 20	
BV4	Lira 50		Lira 50	Lira 50	Lira 50	
BV5	Lira 100		Lira 100	Lira 100	Lira 100	
BV6	Lira 200		Lira 200	Lira 200	Lira 200	

RS232 A0 INFORMATION


Bi ll Type Data							
Code	Denomination						
1	Reserved						
2	Reserved						
3	Lira 5						
4	Lira 10						
5	Lira 20						
6	Lira 50						
7	Lira 100						
8	Lira 200						

Appendix

XBA-TRY6 (Pulse/JPSTD/ccTalk/ICT/RS232 A0)

	FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Pulse Mode	Other Mode								
	Inhibit Active HIGH		ON							
*	Inhibit Active LOW		OFF							
	Reserved			ON						
*	Reserved			OFF						
	Reserved				ON					
*	Reserved				OFF					
	Reserved					ON				
*	Reserved					OFF				
*	Credit-Pulse Normal HIGH	ccTalk 16-bit Encryption mode & Restoe Mode (See Table.1)					ON			
	Credit-Pulse Normal LOW	ccTalk 16-bit Decrypt mode & 8-bit checksum (See Table 1)				OFF				
*	Pulse Mode							ON		
	Other Mode							OFF		
*	1 pulse / Lira 5	ccTalk Mode							OFF	OFF
	5 pulses / Lira 5	RS232 A0 Mode			OFF	ON				
	10 pulses / Lira 5	ICT104U Mode				ON	OFF			
	25 pulses / Lira 5	JPSTD Mode				ON	ON			

This dip switch is located on the CPU board, remove the CPU board cover first.



★ Manufacture setting

Note: 1.Affer setting dip switch of the credit pulses, you should reset the bill acceptor again.

- 2.CCTalk address to its default value of 40 and the encryption key to its default value of 123456.
- 3.Calibration card is needed.

© 2013 International Currency Technologies Corporation Vol. 2.0 Part Number : SWT9TR620-R