



# MTL4

## P77/P5 DIP SWITCHES SETTING : 1

Supported bill Lm 2(old, 94), 5(old, 94), 10(old, 94), 20(old, 94)  
4bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / Lm 1	OFF	OFF	OFF							
2 Pulse / Lm 1	OFF	OFF	ON							
3 Pulse / Lm 1	OFF	ON	OFF							
4 Pulse / Lm 1	OFF	ON	ON							
5 Pulse / Lm 1	ON	OFF	OFF							
10 Pulse / Lm 1	ON	OFF	ON							
20 Pulse / Lm 1	ON	ON	OFF							
100 Pulse / Lm 1	ON	ON	ON							
Fast output Pulse Lo= 50ms Hi=100ms				ON						
★ Slow output Pulse Lo= 50ms Hi=300ms				OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept Lm 2						ON				
Reject Lm 2						OFF				
★ Accept Lm 5							ON			
Reject Lm 5							OFF			
★ Accept Lm 10								ON		
Reject Lm 10								OFF		
★ Accept Lm 20									ON	
Reject Lm 20									OFF	
★ HOLD										ON
										OFF

★ Manufacture setting

Note: (1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

## DIP SWITCHES SETTING : 2

FUNCTION	SW1	SW2	SW3	SW4	
★ Pulse Normal High	ON				
Pulse Normal Low	OFF				
Pulse Protocol					ON
ICT Protocol					OFF
HOLD			ON		
			OFF		
Ignore Sensor Problem(Note 1)				ON	
★ Acknowledge Sensor Problem (Note 2)				OFF	

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)