

TAO-A/V-MUP8

TAO-A/V Option Switch Settings: 1

Supported bill MXP 20, 50, 100, 200
 USD 1, 5, 10, 20 8bills.

TAO-A/V dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject MXP 20 & USD 1	ON											
★ Accept MXP 20 & USD 1	OFF											
★ Reject MXP 50 & USD 5		ON										
★ Accept MXP 50 & USD 5		OFF										
★ Reject MXP 100 & USD 10			ON									
★ Accept MXP 100 & USD 10			OFF									
★ Reject MXP 200 & USD 20				ON								
★ Accept MXP 200 & USD 20				OFF								
★ Accept Mexico Pesos and US Dollars (Note 1)					ON							
★ Accept Mexico Pesos Only (Note 1)					OFF							
★ Reserved						ON						
★ Reserved						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / MXP 10									OFF	OFF		
★ 2 pulse / MXP 10									ON	OFF		
★ 5 pulse / MXP 10									OFF	ON		
★ 10 pulse / MXP 10									ON	ON		
★ Interface Timing Conversion	50ms on / 50ms off										OFF	OFF
	60ms on / 300ms off										ON	OFF
	30ms on / 50ms off										OFF	ON
	150ms on / 150ms off										ON	ON

◆ Factory configuration has all switches in the OFF position.

Note : (1) For Accepting US Dollars, make sure you have dip 5 set to ON position.

(Exchange rate on USD to MXP is 1:10)

(2) Reset the bill acceptor after setting the dip switch.

(3) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

TAO-A/V-MUP8

A TYPE Interface Settings: 2(Pulse/RS232)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ RS232 Interface		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ RS232 Interface		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting

V TYPE Interface Settings: 2(Pulse/M.D.B)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ M.D.B Interface		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting

INTERFACE	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	OFF			
★ Pulse Mode		ON		
★ M.D.B Interface		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting

