V7-KRW3

V7 Option Switch Settings: 1 (Pulse/ICT004/MDB)

Supported bill   KRW   1000, 5000, 10000   3bills.

V7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject KRW 1000	ON											
★ Accept KRW 1000	OFF											
Reject KRW 5000		ON										
★ Accept KRW 5000		OFF										
Reject KRW 10000			ON									
★ Accept KRW 10000			OFF									
Reserved				ON								
★ Reserved				OFF								
Reserved					ON							
★ Reserved					OFF							
Reserved						ON						
★ Reserved						OFF						
Harness Disable							ON					
★ Harness Enable							OFF					
Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 Pulse / KRW1000									OFF	OFF		
5 Pulses / KRW1000									ON	OFF		
10 Pulses / KRW1000									OFF	ON		
20 Pulses / KRW1000									ON	ON		
★ Pulse Speed — 50ms LO / 50ms HI											OFF	OFF
Pulse Speed — 60ms LO / 300ms HI											ON	OFF
Pulse Speed — 30ms LO / 50ms HI											OFF	ON
Pulse Speed — 150ms LO / 150ms HI											ON	ON

◈ Factory configuration has all switches in the OFF position.

★ Manufacture setting

V7-KRW3(Pulse/ICT004/MDB)

V7 Interface Settings: 3 (Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal High	ON			
Credit-Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
MDB Interface		OFF	OFF	
ICT004 Interface		OFF	ON	
Reserved		ON	ON	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting

V7 Interface Settings: 3 (ICT004)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON	OFF	
★ MDB Interface		OFF	OFF	
ICT004 Interface		OFF	ON	
Reserved		ON	ON	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting

V7 Interface Settings: 3 (MDB)

INTERFACE	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 10 Decimal Point Position (DPP) = 1	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
★ MDB Interface		OFF	OFF	
ICT004 Interface		OFF	ON	
Reserved		ON	ON	
★ Reserved				ON
Reserved				OFF

★ Manufacture setting

Currency Assign Data

Interface / Bill value	ICT004	Pulse	MDB
BV1	KRW 1000	KRW 1000	KRW 1000
BV2	KRW 5000	KRW 5000	KRW 5000
BV3	KRW10000	KRW10000	KRW10000

Note: 1.Default setting.
2.Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
3.Remove the front cover and the dip-switch in on the CPU board.
   (Please refer to "Sw1" setting.)