

V7-SAR5

V7 Option Switch Settings: 1 (Pulse/ICT004U/MDB)

Supported bill SAR 1, 5, 10, 50, 100 5bills.

V7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
★ Reject SAR 1	ON							
★ Accept SAR 1	OFF							
★ Reject SAR 5		ON						
★ Accept SAR 5		OFF						
★ Reject SAR 10			ON					
★ Accept SAR 10			OFF					
★ Reject SAR 50				ON				
★ Accept SAR 50				OFF				
★ Reject SAR 100					ON			
★ Accept SAR 100					OFF			
★ Reserved						ON		
★ Reserved						OFF		
★ Harness Disable							ON	
★ Harness Enable							OFF	
★ Inhibit Active High								ON
★ Inhibit Active Low								OFF

◆ Factory configuration has all switches in the OFF position.

V7 Interface Settings: 2 (Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ 1 pulse / SAR 1	OFF	OFF		
★ 2 pulses / SAR 1	ON	OFF		
★ 4 pulses / SAR 1	OFF	ON		
★ 20 pulses / SAR 1	ON	ON		
★ 50ms LO / 50ms HI			OFF	OFF
★ 60ms LO / 300ms HI			ON	OFF
★ 30ms LO / 50ms HI			OFF	ON
★ 150ms LO / 150ms HI			ON	ON

★ Manufacture setting

V7-SAR5(Pulse/ICT004U/MDB)

V7 Interface Settings: 3 (ICT004U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
★ Reserved	OFF			
★ Pulse Mode		ON	OFF	
★ MDB Interface		OFF	OFF	
★ ICT004U Interface		OFF	ON	
★ Reserved		ON	ON	
★ Reserved				ON
★ Reserved				OFF

★ Manufacture setting

V7 Interface Settings: 3 (Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal High	ON			
★ Credit-Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
★ MDB Interface		OFF	OFF	
★ ICT004U Interface		OFF	ON	
★ Reserved		ON	ON	
★ Reserved				ON
★ Reserved				OFF

★ Manufacture setting

V7 Interface Settings: 3 (MDB)

INTERFACE	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
★ Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★ Pulse Mode		ON	OFF	
★ MDB Interface		OFF	OFF	
★ ICT004U Interface		OFF	ON	
★ Reserved		ON	ON	
★ Reserved				ON
★ Reserved				OFF

★ Manufacture setting

Note: 1.Default setting.

2.Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

3.Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "Sw1" setting.)

Currency Assign Data

Interface Bill value	ICT004U	Pulse	MDB
BV1	SAR 1	SAR 1	SAR 1
BV2	SAR 5	SAR 5	SAR 5
BV3	SAR 10	SAR 10	SAR 10
BV4	Reserved	Reserved	Reserved
BV5	SAR 50	SAR 50	SAR 50
BV6	SAR 100	SAR 100	SAR 100