#### V7-TRY6

# V7 Option Switch Settings: 1 (Pulse/MDB/ICT004U)

Supported bill TRY 5, 10, 20, 50, 100, 200

6bills.

V7 dip-switch settings and functions:

				101.01						
	FUNCTION		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
	Reject TRY	5	ON							
*	Accept TRY	5	OFF							
	Reject TRY	10		ON						
*	Accept TRY	10		OFF						
	Reject TRY	20			ON					
*	Accept TRY	20			OFF					
	Reject TRY	50				ON				
*	Accept TRY	50				OFF				
	Reject TRY 1	00 & 200					ON			
*	Accept TRY 1	00 & 200					OFF			
	Reserved							ON		
*	Reserved							OFF		
	Harness Disab	le							ON	
*	Harness Enab	le							OFF	
	Inhibit Active Hi	igh								ON
*	Inhibit Active Lo	ow								OFF

Factory configuration has all switches in the OFF position.

## **V7 Interface Settings: 2 (Pulse)**

	INTERFACE	SW1	SW2	SW3	SW4
*	1 pulse /TRY 5	OFF	OFF		
	5 pulses / TRY 5	ON	OFF		
	10 pulses / TRY 5	OFF	ON		
	20 pulses / TRY 5	ON	ON		
*	50ms Lo / 50ms Hi			OFF	OFF
	60ms Lo / 300ms Hi			ON	OFF
	30ms Lo / 50ms Hi			OFF	ON
	150ms Lo / 150ms Hi			ON	ON

<sup>★</sup> Manufacture setting

### V7-TRY6(Pulse/MDB/ICT004U)

#### **V7 Interface Settings: 3 (ICT)**

#### **V7 Interface Settings: 3 (Pulse)**

	INTERFACE	SW1	SW2	SW3	SW4
	Reserved	ON			
*	Neserveu	OFF			
	Pulse Mode		ON	OFF	
	MDB Mode		OFF	OFF	
*	ICT Mode		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
*	Neserveu		OFF		

	INTERFACE	SW1	SW2	SW3	SW4
Ł	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low				
۲	Pulse Mode		ON	OFF	
	MDB Mode		OFF	OFF	
	ICT Mode		OFF	ON	
	Reserved		ON	ON	
	Reserved				ON
۲	Nesciveu		OFF		

★ Manufacture setting

Interface Settings: 3 (MDB)					Curre	ncy A	ssign	Data
INTERFACE	SW1	SW2	SW3	SW4	Interface Bill value	ICT	Pulse	MDB

ı	INTERFACE	SW1	SW2	SW3	SW4
۲	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
ı	Pulse Mode		ON	OFF	
7	MDB Mode		OFF	OFF	
	ICT Mode		OFF	ON	
ı	Reserved		ON	ON	
ı	Reserved				ON
٦	Neserveu				OFF

Bill value	ICT	Pulse	MDB		
BV1	TRY 5	TRY 5	TRY 5		
BV2	TRY 10	TRY 10	TRY 10		
BV3	TRY 20	TRY 20	TRY 20		
BV4	TRY 50	TRY 50	TRY 50		
BV5	TRY 100	TRY 100	TRY 100		
BV6	TRY 200	TRY 200	TRY 200		

Note: 1.Default setting

2.Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

3. Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "Sw1" setting.)

<sup>★</sup> Manufacture setting

<sup>★</sup> Manufacture setting