

V7E Option Switch Settings: 1(Pulse/ccTalk)

Supported bill Euro 5, 10, 20 3bills.

V7E dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject Euro 5	ON											
★	Accept Euro 5	OFF											
	Reject Euro 10		ON										
★	Accept Euro 10		OFF										
	Reject Euro 20			ON									
★	Accept Euro 20			OFF									
	Reserved				ON								
★	Reserved				OFF								
	Reserved					ON							
★	Reserved					OFF							
	High Acceptance						ON						
★	High Security						OFF						
	Harness Disable							ON					
★	Harness Enable							OFF					
	Inhibit Active High								ON				
★	Inhibit Active Low								OFF				
★	1 pulse / Euro 5									OFF	OFF		
	5 pulse / Euro 5									ON	OFF		
	10 pulse / Euro 5									OFF	ON		
	20 pulse / Euro 5									ON	ON		
★	Pulse Speed	50ms on / 50ms off								OFF	OFF		
		60ms on / 300ms off								ON	OFF		
		30ms on / 50ms off								OFF	ON		
		150ms on / 150ms off								ON	ON		

★ Manufacture setting

◆ Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ccTalk Interface		OFF	OFF	
	ccTalk Parameters Restore Switch		OFF	ON	
	Reserved				
★					OFF

★ Manufacture setting

DIP SWITCHES SETTING : 3(ccTalk)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ccTalk Interface		OFF	OFF	
	ccTalk Parameters Restore Switch (Note 2)		OFF	ON	
★	Encryption Mode				
	Decrypt Mode				OFF

★ Manufacture setting

Note: (1) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(2) ccTalk Parameters Restore Switch

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.